

## dcbel Installation Single Line Diagram 120/240 Vac Split Phase Grid Countries





## dcbel Installation Wiring Diagram

120/240 Vac Split Phase Grid Countries



<sup>\*</sup>Required for residential installations that want to self-generate to power their homes in countries with a +120/-120V split phase grid unless the home has a 3 phase grid connection with 240V available or smart breaker panel with an auto-transformer. Additional supporting hardware may be required depending on local regulations.



